


smart-retract rebel[™] safety knife #E12304-4

auto-retract rebel[™] safety knife #E12209-4







TO REMOVE BLADE:



Always pull blade away from body

TO REPLACE BLADE:





SAFETY TIPS: READ BEFORE USING TO AVOID INJURY

NEVER use release button unless intending to remove blade.

*AFTER inserting the blade, always ensure blade is secure before releasing the trigger. Restart the process to replace the blade, if blade is not secure.

NEVER direct the safety knife blade at self or others.

US, Canada, and LatAm customers contact: PHCSupport@safetyproducts.global 1 (800) 229-2233 International customers contact: info@safetyproductsholdings.com +49 (0) 2103 967961-0